

# DREAMBOX


DM 8000 HD PVR DVD

## How-To open the case of the Dreambox DM 8000 HD PVR DVD



## Open the case

1. Slide the left and right side panels back and off of the case, like shown in the photos.



2. Please remove both of the screws on the left and right side of the device.



3. Now remove the screw on the rear.



4. Please lift off the cover.

